

Engineering Specification



Job Name _____
 Job Location _____
 Engineer _____
 Approval _____

Contractor _____
 Approval _____
 Contractor's P.O. No. _____
 Representative _____

MS-8000 Fresh Air Inlet

Specification

Watts MS-8000 fresh air inlet with all nickel bronze plate, and spring loaded securing mechanism.



Call customer service if you need assistance with technical details.

Model	Pipe Size A	B	C	D	E
MS-8034	3", 4"(76, 102)	5 1/4"(133)	8"(203)	3/4"(20)	5 1/4"(133)
MS-8056	5", 6"(127, 152)	7 3/8"(187)	10"(254)	3/4"(20)	5 3/4"(146)

NOTICE

The information contained herein is not intended to replace the full product installation and safety information available or the experience of a trained product installer. You are required to thoroughly read all installation instructions and product safety information before beginning the installation of this product.

Watts product specifications in U.S. customary units and metric are approximate and are provided for reference only. For precise measurements, please contact Watts Technical Service. Watts reserves the right to change or modify product design, construction, specifications, or materials without prior notice and without incurring any obligation to make such changes and modifications on Watts products previously or subsequently sold.



USA: T: (800) 338-2581 • Watts.com
Canada: T: (888) 208-8927 • Watts.ca
Latin America: T: (52) 55-4122-0138 • Watts.com